






TF5000PVR & TF5010PVR - MP3 usage

To download MP3's to Topfield PVR:

- 1] Download Windows Utilities package from topfield-newzealand.co.nz website downloads page.
- 2] Install.
- 3] Plug PVR into standard USB cable from PC
- 4] Run Altair MP3 uploader. Load MP3s into folder on PVR for music files.

To play MP3s properly:

- 1] Go into pre-recorded list by pressing the  button
- 2] Press the  button to move from the TV program list to the MP3 recorded list
- 3] If you wish to have random play use the **BLUE** button to sort MP3 tracks by time instead of alphabetical. This will arrange tracks by length of time, which when played is very like random. Press **BLUE** button again when finished selected sorting type.
- 4] Using the **RED** button select the MP3 tracks you wish to have in your jukebox selection. The PVR will number them.
- 5] Press  PLAY button and your jukebox will play. Ensure you have it connected to your home stereo unit and not just the TV for best results.
- 6] Use  button to move to next track even with TV turned off.
- 7] Use  button to move to previous track even when TV turned off.